



Glide Air Deflector System

Vanderhall Carmel

Installation Instructions

1. **Remove the thin blue protective plastic coating.**
2. Prior to installation remove the acorn nuts on the inside of the windshield supports. The bottom acorn nut can be difficult to remove. Once you loosen the nut you can back out the bottom bolt from the outside just enough to get the nut removed. If so leave it loose until the washer and nut are installed.
3. Slide the deflector in place on the bolts the notch goes down, the deflector flares out. Add a washer then a nut on all three bolts. Remember to install the bottom washer and nut, then tighten the bottom bolt. Snug up the 3 nuts and washers **DO NOT OVER TIGHTEN** as this will cause undue stress on the poly carbonate, there will be a little adjustment in how the deflector will sit.
4. It is advisable to add a small amount of locking agent to the nut Install the nut and tighten snugly.
5. Move to the other side and repeat.

If you are not comfortable installing your deflector, have it professionally installed. Park Road Products LLC (GADS) bears no responsibility for improper installation.

Park Road Products LLC

not affiliated with Vanderhall Motors

