



Glide Air Deflector System

Vanderhall Venice

Installation Instructions

1. **Remove the thin blue protective plastic coating.**
2. Prior to removing, examine the windshield bracket, note how the bracket fits. In order to keep the bracket in alignment replace the screws, **ONE AT A TIME** that hold the windshield in place, with the enclosed matching but longer fasteners. Torque to specifications.
3. Slide the deflector in place on the fasteners, very loosely add a washer then a nut on the bottom hole. Then start the second washer and nut on the top hole. Snug up the nuts and washers **DO NOT OVER TIGHTEN** as this will cause undue stress on the poly carbonate, there will be a little adjustment in how the deflector will sit.
4. It is advisable to add a small amount of locking agent to the cap nut Install the cap nut and tighten snugly.
5. Move to the other side and repeat.

If you are not comfortable installing your deflector, have it professionally installed. Park Road Products LLC (GADS) bears no responsibility for improper installation.

Park Road Products LLC



t affiliated with Vanderhall Motors